

Setting up

- Pull down the line from the rear wheel.



- Turn the line below the Ciro in direction of the pole until it is free.



- Pull up the pole until the line is stretched and the bottom end plug of the line is engaged in the bore of the deck.



- Do not place fingers in between moving parts! You may pinch your fingers and get hurt.

Folding

- Turn down the pole.
- Turn the line around the pole outside.
- Pull the line below the deck towards the rear wheel and stretch it over the outside of the wheel.

Turning

- Turn the handlebar to the left or respectively to the right.



Note! The pole cannot be fixed! So hold the pole next to your body in order the pole does not turn forwards.

- The line is not ment to hold the pole but the deck, so that the Ciro Line can be lifted over a landing or a down step. Never turn the pole beyond the vertical because the line may rip.
- When the steering starts to oscillate, immediately reduce speed.

Braking

- If there is a foot brake, operate it carefully. Locked wheels can develop flat spots and become out of round very fast!
- During braking the brake becomes hot. Touching the brake may lead to burns!
- Do not ride downhill and in the wet, because the brake may become totally ineffective.
- Take care in the wet, because the wheels could loose traction and the Ciro Line could slide!
- Models without brake: slow down and stop the Ciro Line with your stepping leg or jump off in case of emergency.

Checking over

- Check for function and damages before every ride (wear, cracks, dents and so on).
- Regularly tighten all bolts and nuts.
- Before tighten the nut of the front axle screw replace the little set screw, otherwise the thread of the axle screw may be damaged.
- Consult your dealer after accidents or if you discover strange wear patterns.

Looking after

- Regularly wash with neutral cleaner, rinse and dry. Do not use a jet cleaner. Keep bearings dry. Water or other fluids may damage them.
- Clean the wheel bearings on a regularly basis. Replace worn wheel bearings immediately.
- After cleaning, check all parts for wear and dents and tighten all screws and nuts.

Content

- 1 x Ciro Line
- 2 x box spanner 13mm
- 2 x hex key wrench 5mm
- 1 x hex key wrench 2,5mm

Spare parts and accessories can be ordered from:

Ciro Shop - Straka.DES
Markt 2
08340 Schwarzenberg
Germany
fon: 0049-(0)3774-17643828
fax: 0049-(0)3774-17643817
mail: shop@ciro.de
web: www.ciro.de

Code of Responsibility

- Your Ciro Line scooter is not a toy. Do not let children use it.
- Be aware that Ciro scootering, like other recreational activities, involves inherent and other risks which may lead to injury or even death. Maintain caution, presence of mind and control of speed in all situations to ride safely.
- Wear shoes with rubber soles. Protective gear including helmet, wrist guards, elbow and knee pads are strongly recommended. Understand that no amount of protective gear can protect you in all situations.
- Never ride under the influence of drugs or alcohol.
- Become familiar with your Ciro Line scooter, learn how to step, turn and stop.
- Follow the highway code, avoid areas with heavy traffic.
- Watch the traffic carefully, look ahead and give way if necessary. Alert other road users of your presence, especially pedestrians when passing.
- Never allow yourself to be pulled by other vehicles. Do not use your Ciro on wet, oily, icy or rough uneven surfaces.
- Do not pull or push the joystick/handlebar pole while in motion. Do not lean back, do not jump over landings or down steps as the pole is not fixed and may turn down.
- Keep your Ciro Line scooter in good running order. Do not modify it in any way as this could bear risks and will invalidate your warranty.
- Your responsibility is without limitation to the above.
- In addition to this code you should be in good physical condition.


Warranty

Ciro Line scooter are guaranteed against defects in material and manufacturing for the warranty period provided by law ** from the date of purchase. The warranty only covers the defective component, not the complete Ciro Line scooter. The warranty excludes damage due to transport or storage. All responsibility is declined in case of not following the instructions for use, wear and tear (especially wheels, bearings, steering leaf, brakes, lines and handlebar grips), use other than for which the Ciro Line scooter has been designed, poor maintenance and servicing or damage caused by accident or fall. If a claim is entered into, a substitute or repair will be provided within a suitable period. The buyer covers all costs for packaging and transportation, If components or entire Ciro Line scooter are sent without consent or a claim is found to be unwarranted. This warranty only covers products sold by an authorized dealer and applies to the first user and is not transferable. For warranty service present the defective product together with the original sales receipt to your nearest authorized Ciro dealer. Your statutory rights are not affected.

** The warranty period may vary from country to country.

Ciro Shop - Straka.DES
Markt 2
08340 Schwarzenberg
Germany
fon: 0049-(0)3774-17643828
fax: 0049-(0)3774-17643817
mail: shop@ciro.de
web: www.ciro.de

State: 01.01.13



Instructions for Use
for your Ciro Line Scooter
read full instructions before setting off