

# Mounting Instructions Kit Softtail

## Content

1x pre-assembled Kit Softtail  
4x fastening screws for the frame  
1x rubber washer  
1x mounting instructions

## Required tools

1x ring(fork) spanner 10mm  
1x socket wrench 10mm  
1x hex key wrench 4mm  
(1x hex key wrench 5mm)

## Notes

Mounting of this kit requires skill and dexterity.  
If it is too risky to you, better let a specialist mount this kit for you.  
Screw tightly all screws. After a ride of ca. 10 - 15 Km retighten all screws.

## Disassembling

1. Unscrew the deck.
2. Unscrew the brakepedal.
3. Unscrew the black resin brake leaf spring.
4. Unscrew the axle screw, take out the wheel (wheelz), washers and spacer.  
Lay aside washers and spacer, just in the order they were mounted before.
5. Unscrew the rear forks.

## Assembling

1. Screw the pre-assembled Kit Softtail on the frame with the new fastening screws.
2. Fit the rubber washers from below the deck on the countersunk screws of the deck, the old one in front, the new one in rear. After that, screw tightly the deck.
3. Fit the rear wheel (wheelz), all washers and spacer to the rear forks (mind the right order).
4. Fit the brake pedal on the new, already pre-assembled brake leaf spring.

## Tuning

If the ground clearance appears to be too low, or the shock compression seems to be too high, the top eyelet of the shock can be changed to the existing second position.  
This is recommended too, if the wheel diameter is less than 100mm.