

Code of Responsibility

- Be aware that Ciro-boarding, like other recreational activities, involves inherent and other risks which may lead to injury or even death. Maintain caution, presence of mind and control of speed in all situations to board safely.
- Wear shoes with rubber soles. Protective gear including helmet, wrist guards, elbow and knee pads are strongly recommended. Understand that no amount of protective gear can protect you in all situations.
- Never ride under the influence of drugs or alcohol.
- Become familiar with your Ciro-board, learn how to mount, turn and stop.
- Follow the highway code, avoid areas with heavy traffic.
- Watch the traffic carefully, look ahead and give way if necessary. Alert other road users of your presence, especially pedestrians when passing.
- Never allow yourself to be pulled by other vehicles.
- Do not use your Ciro on wet, oily, icy or rough uneven surfaces.
- Do not pull or push the handlebar pole while in motion.
- Do not lean back, do not jump over over landings or down steps as you may unhinge the handlebar pole and crash.
- Keep your Ciro-Board in good running order. Do not modify it in any way as this could bear risks and will invalidate your warranty.
- Your responsibility is without limitation to the above. In addition to this code you should be in good physical condition.

Setting up

- Set Ciro-Board down on its wheels.
- Hold Ciro-Board down by placing one foot on the stepping board (between handlebar pole and board).
- Pull the handlebar upright until it locates in it's setting
- Check the handle pole to be locked in its seats securely.
- Be careful not to place fingers in between moving parts!

Folding

- Keep one foot on the board.
- Pull handlebar vertically upwards until it dislocates.
- Fold handlebar down towards the stepping board.

Turning

- Move handlebar to the right or left, wheels follow suit. Do not pull or jerk the handlebar, use balance to steer.
- When the wheels follow an unevenness, correct direction of travel carefully.
- When the steering starts to oscillate, immediately reduce speed.

Braking

- Operate the brake carefully. Locked wheels can develop flat spots and become out of round very fast!
- During braking the brake becomes hot. Touching the brake may lead to burns!
- Models without discbrake: do not ride downhill and in the wet, because the brake may become totally ineffective!
- Take care in the wet, because the wheels could loose traction and the Ciro-Board could slide!

Checking over

- Check for function and damages before every ride:
- Models with discbrake only: pull the brake lever for 30 seconds. The brake lever must not slacken.
- If the lever slackens, the brake system is leaky. Don't ride on, see your authorized dealer immediately for repair.
- Check all parts for cracks and dents. Replace damaged parts immediately!
- Mind for wear in steering, steering pole and wheelz!
- Regularly tighten all bolts and nuts, especially wheel- and tracking rod bolts.
- Consult your dealer after accidents or if you discover strange wear patterns.

Looking after


- Regularly wash with neutral cleaner, rinse and dry.
- Do not use a jet cleaner. Keep bearings dry. Water or other fluids may damage them.
- After cleaning, check all parts for wear and dents.
- Clean the wheel bearings on a regularly basis. Replace worn wheel bearings.

Warranty

Ciro-Boards are guaranteed against defects in material and manufacturing for the period of six month** from the date of purchase. The warranty only covers the defective component, not the complete Ciro-Board. The warranty excludes damage due to transport or storage. responsibility is declined in case of not following the instructions for use, wear and tear (especially wheels, bearings, tracking rod, brakes, brakepads and hoses, stepping boards and handlebar grips), use other than for which the Ciro-board has been designed, poor maintenance and servicing or damage caused by accident or fall. If a claim is entered into, a substitute or repair will be provided within a suitable period. The buyer covers all costs for packaging and transportation, if components or entire Ciro-Boards are sent without consent or a claim is found to be unwarranted. This warranty only covers products sold by an authorized dealer and applies to the first user and is not transferable. For warranty service present the defective product together with the original sales receipt to your nearest authorized Ciro-dealer. Your statutory rights are not affected.

** This warranty may vary in some countries.

How to mount the wheelz



put the axle screw from the outside through the wheel (hollow side of the spokes is the inside; note the turning direction)

first slide the spacer (or little washer, depending on model)

then the big washer onto the screw

insert all into the bore of the bracket

position the nylon nut from the inside ahead the bore

last screw tight the axle screw (spanner 13mm) and check the running performance

How to mount the handlebar



slide the handlebar trough the stem

position the handlebar so that the space for the grips is equal

tighten the handlebar screws

adjust the stem across the riding direction and tighten the screws

slide the grips on the handlebar

check the strength against twisting of stem and handlebar

Ciro Shop - Straka.DES
Markt 2
08340 Schwarzenberg
Germany
fon: ++(0)3774-17643828
fax: ++(0)3774-17643817
mail: shop@ciro.de
web: www.ciro.de

All rights reserved © 2007

How to mount the fenders



insert the plastic rivets from the inside into the fenders

insert the rivets into the bores of the bracket

note, that all of the rivets is inserted

push the pins into the rivets (if neccessary, use a hammer)

Tip

If the grips are loose, clean the handle bar and grips with spirit

If this does not help, do some hair spray onto the handle bar and push the grips on immediately (wait until the spray is dry before use)

If the tracking rod squeaks, drop a bit of oil at the bolts

Content

- 1 x Giro-Board
- 1 x handlebar *
- 2 x wheelz *
- 2 x axle screw *
- 2 x big washer *
- 2 x spacer (or little washer depending on model) *
- 2 x nylon nut *
- 1 x box spanner 13mm
- 1 x hex key wrench 5mm

*) Only if the product is partly assembled. For spare parts and accessories see your local dealer or contact us directly.

Instructions for Use of Giro-Boards

read full instructions before setting off!



giro®